



HYDRANTS SHALL BE SET IN 4 CUBIC FEET OF CRUSHED STONE TO ALLOW FOR PROPER DRAINAGE OF THE HYDRANT. RECOMMENDATIONS OF THE AWWA SHOULD BE FOLLOWED WHEN INSTALLING THE HYDRANTS.

POST HYDRANTS SHALL BE KUPFERLE ECLIPSE # 2 AND SHALL NOT BE USED ON MAINLINES LARGER THAN 4"

POST HYDRANT INSTALLATION