



NOTE:  
SADDLES SHALL BE MODEL FORD  
S70 FOR PVC AND FORD S90 FOR  
C900.  
TAP SET AT 12 O'CLOCK FOR ALL  
AIR RELEASE APPLICATIONS.